


MINI RECIPRO SAW

EXPLODED VIEW



PARTS LIST

Index No.	Parts No.	Description	Qty. Per tool
1	7620-01	Screw	2
2	7620-02	Blade Guide	1
3	7620-03	Head Plate	1
4	7620-04	Steel Plate	1
5	7620-05	Steel Ball	1
6	7620-06	Hex.Screw	1
7	7620-07	Steel Ball	1
8	7620-08	Blade Holder	1
9	7620-09	Under Plate	2
10	7620-10	Under Plate	1
11	7620-11	Hex.Screw	1
12	7620-12	Screw	1
13	7620-13	Head Case	1
14	7620-14	Holder Guide Pin	2
15	7620-15	Snap Ring	1
16	7620-16	Ball Bearing	1
17	7620-17	Gear Shaft Key	1
18	7620-18	Key	1
19	7620-19	Ball Bearing	1
20	7620-20	Crank Shaft	1
21	7620-21	Roller	1
22	7620-22	Gear	1
23	7620-23	Gasket	1
24	7620-24	Gear Case	1
25	7620-25	Lock Ring	1
26	7620-26	Pinion	1
27	7620-27	Ball Bearing	1
28	7620-28	Front End Plate	1
29	7620-29	Collar	1

Index No.	Parts No.	Description	Qty. Per tool
30	7620-30	Rotor	1
31	7620-31	Rotor Blade	4
32	7620-32	Cylinder	1
33	7620-33	Rear End Plate	1
34	7620-34	Ball Bearing	1
35	7620-35	Roll Pin	1
36	7620-36	Motor Housing	1
37	7620-37	O-Ring	1
38	7620-38	Valve	1
39	7620-39	Valve Spring	1
40	7620-40	O-Ring	1
41	7620-41	Regulator	1
42	7620-42	O-Ring	1
43	7620-43	Valve Nut	1
44	7620-44	Sponge A	2
45	7620-45	Valve Shaft	1
46	7620-46	Safety Lever	1
47	7620-47	O-Ring	1
48	7620-48	Deflector	1
49	7620-49	Inlet Bushing	1
50	7620-50	Body Cover	1
51	7620-51	2mm Hex. Wrench	1
52	7620-52	3mm Hex. Wrench	1
53	7610-200	Saw Blade	1